



MULTI-PURPOSE GRINDER INSTRUCTION MANUAL

220~240V

WHCG01SS



CONTENTS

SAFETY INFORMATION

Important Safety Instructions	1 - 2
Electrical Requirements	3

SETUP AND USE

Installation Guide	3
Parts and Features	4
Multi-purpose Grinder Operation	5

CLEANING AND CARE	6
--------------------------------	----------

TROUBLESHOOTING	7
------------------------------	----------

WARRANTY	8 - 9
-----------------------	--------------

Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance.

Product design and specifications may be changed without notice.

IMPORTANT SAFETY INSTRUCTIONS

DANGER

DANGER - Immediate hazards which **WILL** result in severe personal injury or death.















WARNING

WARNING - Hazards or unsafe practices which **COULD** result in severe personal injury or death.


CAUTION

CAUTION - Hazards or unsafe practices which **COULD** result in minor personal injury.

WARNING

1. Read all instructions carefully before using your new multi-purpose grinder. Keep these instructions in a safe place.
2. Always use this multi-purpose grinder with a power outlet of the voltage (A.C. only) marked on the back of the appliance.
3.  **DANGER** Do not operate multi-purpose grinder if:
 - i) the cord or plug is split, melted or damaged.
 - ii) the appliance has malfunctioned.
 - iii) the appliance has been damaged in any manner.If any of the above incidents occur, return the multi-purpose grinder to the nearest authorised service center for examination, repair or adjustment.
4.  **DANGER** Do not under any circumstances immerse the power cord, mains plug or multi-purpose grinder body in water or any other liquid.
5.  **WARNING** Incorrect operation and improper use may damage the multi-purpose grinder or parts thereof, and cause severe personal injury.
6.  **WARNING** When operating the multi-purpose grinder, touch body and buttons only as outer surfaces may become hot whilst the multi-purpose grinder is in use.
7.  **WARNING** Do not blend hot or boiling foods or liquids as there is a risk of burns or scalding.
8.  **WARNING** The multi-purpose grinder blades are very sharp, avoid touching them and handle with care.
9.  **WARNING** Do not plug the appliance to mains before it is fully assembled.
10.  **WARNING** Exercise caution when removing the attachments from the multi-purpose grinder and ensure the appliance is turned off and unplugged whilst fitting attachments.
11.  **WARNING** Keep hands and utensils out of the grinding container while grinding to reduce the risk of severe injury. A scraper may be used but must only be used when the multi-purpose grinder is not running.
12.  **WARNING** Do not handle the appliance with wet hands.
13.  **CAUTION** The multi-purpose grinder should not be left unattended while in operation.
14.  **CAUTION** Keep the multi-purpose grinder and its cord out of reach of children younger than 8 years old.
15.  **CAUTION** It is not recommended to run the multi-purpose grinder continuously for more than 2 minutes at a time for light substances. Do not mix dry, thick or heavy mixtures continuously for more than 30 seconds. Stop the operation and stir the ingredients before continuing.
16.  **CAUTION** Do not use this multi-purpose grinder with any attachment other than the ones supplied.

IMPORTANT SAFETY INSTRUCTIONS

17.  **CAUTION** Do not chop extremely hard food items, such as ice cubes, nutmeg as this may cause damage to the multi-function grinder.
18. Always ensure hands are dry before handling the plug or switching on the appliance.
19. Ensure the multi-purpose grinder is switched off and unplugged from the power source prior to cleaning.
20. This multi-purpose grinder is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the multi-purpose grinder in a safe way by the person responsible for their safety, and understand the hazards involved.
21. Children should be supervised not to play with the multi-purpose grinder.
22. Always turn off the power at the power outlet before you insert or remove the power plug. Remove by grasping the plug - do not pull on the cord.
23. This appliance is intended for non-commercial, indoor use only. Do not use this appliance for anything other than its intended use.
24. Always hold the grinder unit firmly and upright while in use.
25. Always use the appliance on a stable, secure, dry and level surface.
26. This appliance is not intended to be operated by means of an external timer or separate remote-control system.
27. Wait for the multi-purpose grinder to cool before moving.
28. Pay close attention when using this appliance near children.
29. Do not place your multi-purpose grinder on or near a hot gas flame, electric element, heated oven or any hot surface.
30. Do not place the multi-purpose grinder on top of any other appliance.
31. Do not permit the mains supply cord or plug to touch hot objects, or allow the power cord to lay across the multi-purpose grinder body or blades.
32. Do not allow the power cord of this appliance to hang over the edge of a table or bench top.
33. Do not use harsh or abrasive cleaning agents or any sharp instruments for cleaning the appliance. When the appliance is cool to touch, the outside surface may be wiped clean with a soft, damp cloth and then dried thoroughly. If necessary, a mild dishwashing detergent may be applied to the cloth but not directly applied to the multi-purpose grinder.
34. Immediately unplug the multi-purpose grinder from mains power if malfunction occurs.
35. If the appliance has been dropped or damaged, it should not be used until examined by an authorised service center.
36. If the mains supply cord is damaged, it must be replaced by the manufacturer, it's service agent or a similarly qualified person in order to avoid a hazard.
37. For added safety, electrical appliances should be connected to a power outlet that is protected by a residual current device (RCD), also often referred to as a 'Safety Switch'. Your switchboard may already incorporate an RCD. If unsure, call an electrician for verification and fitting if necessary.
38. This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - residential farm houses;
 - by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments.

ELECTRICAL REQUIREMENTS

POWER SUPPLY CORD

1. Do not attempt to modify the power cord or plug in any way.
2. A short power supply cord is provided to reduce the risk of entanglement or tripping over.
3. If the power supply cord is too short, do not use an extension cord. Have a qualified electrician or serviceman install an outlet near the appliance.

NOTE: Neither Westinghouse nor the retailer can accept any liability for damage to the product or personal injury resulting due to failure to observe the electrical connection procedures.

INSTALLATION GUIDE

1. Carefully unpack your electric multi-purpose grinder.
2. Carefully remove packaging around the multi-purpose grinder and straighten the power cord. Do not remove warning labels.

⚠ DANGER Do not under any circumstances immerse the power cord, mains plug or grinder main body in water or any other liquid.

⚠ WARNING The multi-purpose grinder's blades are very sharp, avoid touching them and handle with care.


PARTS AND FEATURES




1. Grinder Lid
2. Grinder Main Body
3. Power Button
4. Cord Storage


MULTI-PURPOSE GRINDER OPERATION

1. Ensure unit is unplugged from wall power outlet.
2. Add ingredients into the bowl, being careful not to touch the blades.
3. Place lid onto the bowl and ensure it is locked onto the unit by turning clockwise.
4. Ensuring your fingers are not pressing the button on the front of the grinder body, plug the power cord into the A/C outlet and switch on.
5. Begin operation by pressing the power button on the front of the grinder body.
6. Once your ingredients are ground to your desired size, release the power button. Ensure the power to the unit is turned off and the unit is unplugged from the wall power outlet before removing the ground contents.

 **WARNING** The multi-purpose grinder blades are very sharp, avoid touching them and handle with care.


 **WARNING** Do not plug the appliance into power before it is fully assembled.


 **WARNING** Do not pour water or any liquid directly into the bowl as it is not water tight and will cause damage to the electrical components and pose an electrical shock hazard.


 **CAUTION** It is not recommended to run the multi-purpose grinder continuously for more than 2 minutes at a time for light substances. Do not mix dry, thick or heavy ingredients continuously for more than 30 seconds. Allow the motor to rest for 1 minute between each use.

CLEANING & CARE

1. Remove the lid from the main body and wash the lid with warm water and mild detergent. DO NOT submerge the grinder body in water under any circumstances.
2. Rinse the lid with fresh water and then ensure the lid is dried thoroughly before placing back into storage.
3. Wipe the inner grinder bowl with a damp cloth only, being careful to avoid the blades, and ensure to dry afterwards.
4. Store in a dry place away from steam and humidity where possible.

 **DANGER** Do not under any circumstances immerse the power cord, mains plug or grinder body in water or any other liquid.

 **WARNING** The multi-purpose grinder blades are very sharp, avoid touching them and handle with care.

 **WARNING** Do not pour water or any liquid directly into the bowl as it is not water tight and will cause damage to the electrical components and pose an electrical shock hazard.

TROUBLESHOOTING

BEFORE CALLING FOR SERVICE

If the multi-purpose grinder fails to operate:

1. Check to make sure the multi-purpose grinder is plugged in correctly and securely. If it is not, remove the plug from the outlet, wait 10 seconds and plug it back in securely
2. Check for a blown or tripped circuit breaker in your home. If these seem to be working correctly, test another appliance in the same outlet to ensure the outlet is working correctly.

IF NONE OF THE ABOVE SOLVES THE PROBLEM, DO NOT TRY TO ADJUST OR REPAIR THE MULTI-PURPOSE GRINDER YOURSELF.

CUSTOMER SERVICE

In the event you believe your multi-purpose grinder to be defective, please return it along with your sales receipt to the place of purchase for resolution.

For any enquiries, please call our service center on: Tel: 1300 883 109

TROUBLESHOOTING

Troubleshoot your problem by using the chart below. If the multi-purpose grinder still does not operate correctly, it may be defective.

TROUBLE	POSSIBLE CAUSE	POSSIBLE REMEDY
Multi-purpose grinder does not turn on.	Multi-purpose grinder is not plugged in.	Check that multi-purpose grinder is plugged into a working power outlet and turned on.
Motor slowing down and appears to be struggling while in use.	Foods are too dense or too much food in the bowl.	Reduce quantity of food and try again.

LIMITED WARRANTY

1. Nothing in this warranty affects the Consumer's rights under the Australian Consumer Law. The benefits to the Consumer under this Warranty are in addition to the rights and remedies of the buyer under any Consumer Guarantees. The Australian Consumer Law requires that we confirm that:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
2. Subject to Clause 1, the Seller warrants that Westinghouse branded products will be free of manufacturing defects and will perform to the Seller's specifications subject to the following clauses.
3. The benefit of this Warranty extends only to the owner of the property in which the Products manufactured or supplied by the Seller are installed and used by the owner for the duration of the Warranty Period.
4. The Warranty commences on the date of the purchase of the product and continues for the benefit of the Owner for the Warranty Period. If within the Warranty Period a manufacturing defect is discovered in the Product, or the Product fails to perform to the Seller's specifications as a result of some defect in material or workmanship in the Product, then the Seller will at its own discretion:
 - a.) Repair or replace the Product at the cost of the Seller, including but not limited to labour and travel costs. Goods repaired or replaced under this Warranty will be warranted for the remaining period of the Warranty.
 - b.) Refund the purchase price paid by the consumer.
5. The Warranty does not apply to Product that:
 - a.) Has failed due to excessive wear and tear beyond what is considered to be reasonable.
 - b.) Has been misused or neglected.
 - c.) Has been damaged accidentally or by acts of God including fire and flooding.
 - d.) Has been used or operated contrary to operating or maintenance instructions.
 - e.) Has been damaged by the Consumer or a third party authorised to act for the consumer in transit from the Sellers store to the Consumer.
6. In order to make a claim under the Warranty, the Owner must, where possible return the goods to the Seller's store at the Owner's cost. Proof of purchase must be supplied in all cases.
7. The seller will examine any returned Products and if the Seller determines that there is an apparent defect through no fault of the Owner, the Seller will:
 - a.) Make note of the Owner's contact details including the Owner's telephone number which the owner can be contacted during business hours, postal address and e-mail address.

- b.) Make note of the defects reported by the Owner.
 - c.) Take back the defective goods from the owner and determine within a reasonable time through dialogue with the Seller whether the goods are defective.
 - d.) Advise the owner within a reasonable time frame whether it accepts or rejects the Product claim.
 - e.) If the Seller accepts the return of the Product, the Seller must arrange to have
 - i) The Product repaired or,
 - ii) Replace the damaged or faulty Product or,
 - iii) Refund the purchase price.
8. The Seller will not accept any returned Product which has not been returned strictly in accordance with this Warranty.
9. For the purpose of this Warranty:
- a.) Australian Consumer Law means the law as set out in Schedule 2 of the Competition and Consumer Act 2010 (Cth).
 - b.) Consumer means the Purchaser of goods from the seller.
 - c.) Consumer means a Consumer as that term is set out in section 3 of the Australian Consumer Law.
 - d.) Consumer Guarantees means the guarantees under the Australian Consumer Law.
 - e.) Implied terms means any guarantees, conditions, warranties or other terms implied by any Australian Commonwealth, State or Territory laws, (excluding the Australian Consumer Law) or the law of any other jurisdiction.
 - f.) Owner has the meaning set out in clause 3.
 - g.) Warranty means this warranty.
 - h.) Product means the Product/s bought by the Owner from the Seller that fall under this warranty.
 - i.) Warranty Period means:
 - i) In relation to Cast Iron Cookware: 3 Year Limited Warranty.
 - ii) In relation to Non-Stick Cookware: 3 Year Limited Warranty
 - iii) In relation to Cooking Utensils: 3 Year Limited Warranty
 - iv) In relation to Knives/Knife Block Sets: 3 Year Limited Warranty
 - v) In relation to Stainless Steel Cookware: 10 Year Limited Warranty
 - vi) In relation to Chopping boards: 1 Year Limited Warranty
 - vi) In relation to Small Appliances: 1 Year Limited Warranty



Westinghouse

www.westinghousesmallappliances.com.au

CUSTOMER SERVICE - AU: 1300 883 109
info@westinghousesmallappliances.com.au

CUSTOMER SERVICE - NZ: 0508 776 546
info@westinghousesmallappliances.co.nz

IMPORTED AND DISTRIBUTED BY RVM AUSTRALIA PTY LTD.
11 Tamara Drive, Cockburn Central, WA 6164
MADE IN CHINA

© 2023 RVM AUSTRALIA PTY LTD. ALL RIGHTS RESERVED.

® & WESTINGHOUSE are trademarks of Westinghouse Electric Corporation.
Used under license by RVM AUSTRALIA PTY LTD. ALL RIGHTS RESERVED.