

Television

Reference Guide


参考指南 / Hướng dẫn Tham khảo / Guide de référence /

Справочник / คู่มืออ้างอิง / Panduan Referensi / دليل مرجعي / راهنمای مرجع



































K-85XR90 / 75XR90



https://rd1.sony.net/help/tv/lga1/h_ga/



© 2024 Sony Corporation Printed in Malaysia



	①	②	③	④	⑤
(mm/MM/인치/ milimetro/ milimetro/ milimetro)	A	B	C	D	W
(kg/кг/nn/キログラム/キログラム/キログラム)					
	1888	1085	49	52.4	52.4
K-85XR90	1888	1085	49	52.4	52.4
	1667	960	48	42.3	42.3
K-75XR90	1667	960	48	42.3	42.3

