


90cm Induction Cooktop OCI905TZ

omega


Designed to Enhance
EST. 1981



Introducing your new 90cm Induction Cooktop

Cooktop Overview


- A. Cooktop Controls
- B. Ø210mm Zone × 2
- C. Ø180mm Zone
- D. Ø160mm Zone × 2



Cut-Out Diagram

Shown below are dimensions for your cooktop's benchtop cut-out, as required for its installation.

For minimum distance requirements and safety advice, please refer to your supplied User Manual, pages 04–08.



Details

Product Dimensions (W, D, H): 900 × 520 × 58mm
 Cut-Out (W, D): 860 × 490mm | Warranty: 3 Years

Cooktop Controls

	<p>Zone Selection Used to select and monitor which zones you would like to cook with.</p>
	<p>Temperature Slider Touching the slider increases or decreases the selected zone's temperature setting.</p>
	<p>Timer Function A kitchen timer and a way to automatically shut off zones after a set period of time.</p>
	<p>Start/Pause Button This function is used to temporarily pause cooking, without having to power off.</p>
	<p>Keep Warm This function lowers a zone's heat setting to keep food warm after cooking.</p>
	<p>Child Safety Lock Disables cooktop controls to prevent use, such as accidental activation by children.</p>
	<p>Boost Function Used to increase a zone's heat setting to the maximum level for up to 5 minutes.</p>
	<p>Power Button This button is used to easily power the cooktop both on and off.</p>

For a detailed guide on operating your Omega cooktop, please refer to your supplied User Manual, pages 18–28.

Support

Telephone: 1300 11 HELP (4357)
 Email: support@residentiagroup.com.au

