

DAB & DAB+ Compatible Radio RF-D10GN

| | | |
|-----------------------|-------------------------------------|--------------------------------------------------------|
| | Band/Station Presets | FM 87.5-108.0 MHz (50KHz step) DAB BANDIII (5A-13F) |
| TUNER | DAB | DAB/ DAB+ |
| | FM | yes |
| | RDS | - |
| | Whip Antenna (for FM/ DAB) | 67cm |
| AUDIO SYSTEM | Output Channel | 1ch |
| | Power Output (RMS) | 2W (10% THD) |
| | Total Power | 2W (10% THD) |
| | Configuration | 1 way 1 speaker |
| SPEAKER SYSTEM | Speaker Unit | Full Range: 10cm (4 ohms) |
| | 10 Channel Memory | yes |
| EASY OPERATION | 5 Preset EQ | yes(Flat/ Heavy/ Soft/ Clear/ Vocal) |
| | DAB Scan*¹ | yes |
| | Auto Tune Mode | yes (for FM) |
| | Programable Timer | PLAY/ SLEEP |
| | Battery Level Indication | yes |
| | Clock (Auto Time Adjustment) | yes |
| DESIGN | Display Size (View area) | 74 x 21 mm Large Display |
| | Easy Viewing Screen | yes (with White Backlight) |
| | LCD | yes (with White Backlight) |
| | Digit | 2 x 16 Digits + icons |
| TERMINAL | 10 Direct Select Key | yes |
| | Fold-Down Handle | yes |
| | Earphone/ Headphone (3.5mm) | yes (Stereo Mini) |

| | | | |
|-----------------------------|--------------------------|------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SUPPLIED ACCESSORIES | Power Supply | AC Plug Cord | yes |
| | | AC | 230-240V, 50Hz |
| | | Battery | DC 6V/ C x 4 (R14/ LR14) |
| | | Normal Use [Approx.] | 7W |
| | | Standby [Approx.] | 0.6W |
| | | DAB [Approx.] | 12h/ 40h |
| | | FM [Approx.] | 9h/ 30h |
| | | Dimensions (W x H x D) [Approx.] | 251 x 138 x 91 mm |
| | | Weight (with batteries) [Approx.] | 1.3 kg |
| | | Weight (without batteries) [Approx.] | 1 kg |
| OTHERS | Power Consumption | Battery Life in Use*² - Manganese R14/ Alkaline LR14 | |
| | | DIMENSIONS, WEIGHT | |
| | | NOTE | <p>*1 DAB scan can be done by selecting "Full Scan" from MENU.</p> <p>*2 Use Panasonic batteries.</p> <p>·Specifications are subject to change without notice. Weight and dimensions are approximate.</p> |