

Universal Laundry Pedestal Stand with Locking Drawer



Product Details

FEATURES

Convenient working height

Securely store away cleaning products

Keep your laundry neat and tidy with the handy storage drawer

Durable Construction, built to last

BENEFITS

Convenient working height

The pedestal raises your Front Load Washer or Dryer to an optimal working height for ease of loading or unloading of your laundry.

Safe Storage

Large lockable storage drawer provides a clever way to safely store your laundry essentials so you can keep your laundry neat and tidy whilst keeping little hands away from cleaning products.

Durable Construction

Moisture- resistant durable construction with adjustable rubber feet for stability and noise reduction.

Quick and easy to install*

Easy and efficient installation process. With minimal tools and assistance required. *You may require lifting assistance.

Suitable for most brands

Suitable for most Front Load Washers, Dryers, and Washer/Dryer Combos with a 60cm base.

Specifications

PRODUCT PROFILE

Domestic warranty details (yrs)	1
Product Relates to	Washing Machine,Dryer
Install, Perform, Care	Install

SHIPPING

Shipping Weight (Kg)	22
Pack Dimensions Height (mm)	380
Pack Dimension Width (mm)	670
Pack Dimension Depth (mm)	650

FEATURES

Accessory Other Features	Durable construction,Universal,Suitable for models from most brands,May require assistance moving appliances when installing
--------------------------	--

Terms and Conditions

IMPORTANT

This is a guide of product dimensions only. For complete installation instructions, refer to the manual provided with product.

PRODUCT INFORMATION

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd (Australia) and Electrolux (NZ) Ltd (New Zealand) will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow. Electrolux will at all times comply with its obligations pursuant to law including Trade Practices (Australian Consumer Law) Act and Regulations.

WARRANTY

This warranty only applies to Appliances purchased and used in Australia or New Zealand and used in normal domestic applications and is in addition to (and does not exclude, restrict, or modify in any way) any non-excludable statutory warranties in Australia or New Zealand. All warranties are subject to the conditions set out in the warranty card accompanying the product when purchased.

ELECTROLUX HOME PRODUCTS AUSTRALIA

telephone: 1300 363 640

fax: 1800 350 067

email: customercare@electrolux.com.au

web: www.electrolux.com.au

ELECTROLUX HOME PRODUCTS NEW ZEALAND

telephone: 09 573 2230

fax: 09 573 2221

email: customercare@electrolux.co.nz

web: www.electrolux.co.nz